Urban Winner

URBAN SPORT HELMETS

OWNER'S MANUAL

URBANWINNER.COM

READ THE OWNER'S MANUAL BEFORE WEARING THE HELMET

CE

EN 1078

EUROPEAN SAFETY STANDARD
FOR BICYCLE HELMETS, SKATEBOARD
AND ROLLER SKATE HELMETS

IMPORTANT INFORMATION

This helmet is designed to absorb blows to the head in case of punches or falls reducing the risk of head injuries. Be aware that no helmet can protect against every kind of punch or fall. Try to prevent any kind of accident.

This helmet is not suitable for motorised vehicles and should only be used with push bikes, roller skates and skateboards.

Always assist children with fitting the helmet to ensure a proper fit. Not intended for climbing or playing since children could get caught in the straps, which could lead to strangulation.

If the helmet suffers a severe blow it might lose its ability to protect your head. If this happens the helmet must be replaced. Even minor blows can affect the helmet's ability to protect the head. Do not let children play with the helmet since it might affect its durability. Take care of the helmet and do not let children throw it or play with it.

The helmet is designed only to be used for a natural period of time. This period of time depends on how often it is worn. The helmet should be replaced when signs of wear and tear become visible. Inspect the helmet for wear and tear on a regular basis.

Do not expose your helmet to extreme temperatures; 60º C / 140º F or more. Do not leave your helmet in direct sunlight in a car on a hot summer day. Keep the helmet away from heat sources. High temperatures can damage the helmet.

The varnish on the helmet's surface is not hit and scratch resistant.

When the helmet is not worn store in a dry and clean place away from direct sunlight preferably at room temperature.

PERSONAL FITTING OF THE HELMET

Personal fitting will result in maximum safety and comfort. The helmet is equipped with a replaceable neck adjuster and interchangeable comfort padding in various sizes. Adjust the helmet so it feels comfortable. It is not supposed to feel too loose or too tight. Heads come in different shapes and sizes so please take time fitting the helmet correctly:

Neck adjuster:
Loosen the neck adjuster to its maximum expandable size and put the helmet on.

If the helmet feels too tight please replace the comfort padding inside the helmet with a thinner one (enclosed). Then simply tighten the neck adjuster until the helmet feels comfortable.

If you prefer wearing the helmet without the neck adjuster it can easily be removed. Pull the ends carefully where they are attached to the helmet after which you can easily apply the enclosed Velcro dots.

If the neck adjuster has been removed do not push the helmet backwards once wearing it. If the helmet is pushed backwards it will affect its ability to protect your head.

For optimal safety the helmet should be placed 1-2 fingers above the eyebrows.

Comfort padding:
In order to fit individual head shapes and sizes the pre-installed comfort padding can easily be replaced or mixed with other thickness of padding.

Straps:
Each of the helmet's sides are fitted with two straps which must be joined under each earlobe. Pull the straps so they are close to the face. Make sure the straps are comfortable without being too tight or too loose and make sure the straps are correctly adjusted on a regular basis.

MAGNETIC BUCKLE
Easily lock the helmet and avoid pinching of the skin with the patented and secure magnetic buckle from Fidlock®. To open the magnetic buckle simply slide in the direction of the arrow.

MAINTENANCE OF YOUR HELMET
Wipe down the helmet with a soft and moist cloth.

The comfort padding may be washed by hand with a small amount of mild soap and lukewarm water. Dry at room temperature. Do not machine wash, tumble dry, dry-clean or iron.

EAR WARMERS AND ACCESSORIES
Can be purchased at your local UrbanWinner retailer or on www.urbanwinner.com

CE APPROVED
This helmet meets the European safety standard for bicycle helmets, skateboard and roller skate helmets: CE EN 1078.